



Canon EOS Rebel T1i Battery Replacement

If your camera is running out of batteries or you have a broken battery, then follow this guide to replace the batteries.

Written By: Jonathan Lin



INTRODUCTION

This guide will provide you with instructions to replace your bad or broken battery.



TOOLS:

- [Fingers](#) (1)



PARTS:

- [Battery Pack LP-E5](#) (1)

Step 1 — Battery



- Find the bottom of the device and use your fingers to push down on the latch on the battery door.

Step 2




- ☑ Completely open the battery door with your fingers.

Step 3



- Remove the existing battery with your fingers.

 This is a pseudo-battery.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-17 12:21:31 PM.